

# **GENERAL MAINTENANCE** SIDE SEALERS

### **REQUIRED TOOLS:**


- CLEAN CLOTH
- AIR BLOWER

• TEFLON TAPE

- SAFETY GLOVES
- SCISSORS
- HIGH-TEMPERATURE CHAIN LUBRICANT



## **MAINTENANCE PROCEDURE**





SAFETY ALERT: WEAR SAFETY GLOVES

After the knife has heated up, check knife for any plastic residue. If residue is present, wipe down the hot seal bar with a clean cloth.

#### ALWAYS WEAR APPROPRIATE SAFETY GLOVES WHEN PERFORMING CLEANING FOR A KNIFE.

WWW.BESTPACK.COM

VERSION 1.0\_0924

#### STEP 3 SEAL PAD MAINTENANCE



Check the condition of your Teflon tape. If burnt, it will need to be replaced.

First, remove the Teflon tape from the seal pad. If the sealing pad is in good condition, proceed removing Teflon tape.

#### **STEP 4** TEFLON TAPE MAINTENANCE



Measure and apply the Teflon tape to seal pad.

Trim any excess off the ends of the sealing pad after it's been applied.

#### STEP 5 APPLY TEFLON TAPE



Once Teflon is applied, reattach the sealing pad in its original position.

#### STEP 7 SHRINK TUNNEL MAINTENANCE



If you have a shrink tunnel connected, turn on the shrink tunnel and increase the conveyor speed to maximum.

## STEP 8 SHRINK TUNNEL MAINTENANCE



Apply the lube to the chain evenly and continuously until the chain completes a full rotation.

Repeat the lubrication on the other chain.



#### RELIABLE SUPPORT WHEN YOU NEED IT MOST

The BP360 support program provides you with personalized guidance, expert troubleshooting, and 24/7 support to enhance your solution's performance through:

- BPA Rewards Program
- Access to Real Time Data with DAS
- Phone & Online Support
- 24/7 Resource Web Center via Our Help Website

START EXPLORING HERE: HELP.BESTPACK.COM

## LOOKING FOR SPARE PARTS? CONTACT US AT: ORDERS@BESTPACK.COM



For more information please go to: **WWW.BESTPACK.COM** or call us at **1.888.588.2378**