

GENERAL MAINTENANCE STRETCH PALLET WRAPPERS

REQUIRED TOOLS:

- AIR BLOWER
- GENERAL PURPOSE GREASE
- PAINT BRUSH
- 6MM ALLEN KEY



MAINTENANCE PROCEDURE



Make sure machine is powered off.

Remove the 6 bolts in the center of the turntable using a 6mm allen key.



SAFETY ALERT : DO NOT ATTEMPT TO LIFT

Slide the turnabletable out of the way, pushing it with your foot.



Using compressed air, blow out all residue and trash that is in the turntable base.

THE TURNTABLE IS HEAVY AND DIFFICULT TO HANDLE. DO NOT ATTEMPT TO LIFT THE TURNTABLE UNDER ANY CIRCUMSTANCES.

WWW.BESTPACK.COM

STEP 3 CLEAN TURNABLE BASE



SAFETY ALERT: WEAR SAFETY GLOVES

Check that no trash or plastic is stuck under the center sprocket, remove the plastic if any is present.

Check that all plastic rollers around the turntable are spinning freely.



Use a paint brush and dip it in all purpose grease. Apply the grease to the turntable chain.

STEP 5 GREASE CHAIN



Step back and turn the machine ON, and manual rotate the turntable from the HMI to expose the rest of the chain.

TURN MACHINE BACK OFF.

Continue to apply grease the rest of the chain.

STEP 7 TURNTABLE MAINTENACE



Using your foot, slide turntable back on to the base of the machine.

Rotate the turntable back on to the base of the machine.

STEP 8 TURNTABLE MAINTENACE



Put all 6 bolts back in place and tighten them up in a star pattern.



RELIABLE SUPPORT WHEN YOU NEED IT MOST

The BP360 support program provides you with personalized guidance, expert troubleshooting, and 24/7 support to enhance your solution's performance through:

- BPA Rewards Program
- Access to Real Time Data with DAS
- Phone & Online Support
- 24/7 Resource Web Center via Our Help Website

START EXPLORING HERE: HELP.BESTPACK.COM

LOOKING FOR SPARE PARTS? CONTACT US AT: ORDERS@BESTPACK.COM



For more information please go to: **WWW.BESTPACK.COM** or call us at **1.888.588.2378**